SCTE STANDARDS

Data Standards Subcommittee

AMERICAN NATIONAL STANDARD

ANSI/SCTE 165-21 2016 (R2021)

IPCablecom 1.5 Part 21: Signaling Extension MIB

NOTICE

The Society of Cable Telecommunications Engineers (SCTE) Standards and Operational Practices (hereafter called "documents") are intended to serve the public interest by providing specifications, test methods and procedures that promote uniformity of product, interoperability, interchangeability, best practices, and the long term reliability of broadband communications facilities. These documents shall not in any way preclude any member or non-member of SCTE from manufacturing or selling products not conforming to such documents, nor shall the existence of such standards preclude their voluntary use by those other than SCTE members.

SCTE assumes no obligations or liability whatsoever to any party who may adopt the documents. Such adopting party assumes all risks associated with adoption of these documents and accepts full responsibility for any damage and/or claims arising from the adoption of such documents.

NOTE: The user's attention is called to the possibility that compliance with this document may require the use of an invention covered by patent rights. By publication of this document, no position is taken with respect to the validity of any such claim(s) or of any patent rights in connection therewith. If a patent holder has filed a statement of willingness to grant a license under these rights on reasonable and nondiscriminatory terms and conditions to applicants desiring to obtain such a license, then details may be obtained from the standards developer. SCTE shall not be responsible for identifying patents for which a license may be required or for conducting inquiries into the legal validity or scope of those patents that are brought to its attention.

Patent holders who believe that they hold patents which are essential to the implementation of this document have been requested to provide information about those patents and any related licensing terms and conditions. Any such declarations made before or after publication of this document are available on the SCTE web site at https://scte.org.

All Rights Reserved
© 2021 Society of Cable Telecommunications Engineers, Inc.
140 Philips Road
Exton, PA 19341

Note: DOCSIS® and PacketCableTM are registered trademarks of Cable Television Laboratories, Inc., and are used in this document with permission.

Document Types and Tags

Document Type: Specification		
Document Tags:		
☐ Test or Measurement	☐ Checklist	☐ Facility
☐ Architecture or Framework	☐ Metric	X Access Network
☐ Procedure, Process or Method	☐ Cloud	☐ Customer Premises


Document Release History

Release	Date
SCTE 165-21 2009	10/5/2009
SCTE 165-21 2016	10/31/2016

Note: This document is a reaffirmation of SCTE 165-21 2016. No substantive changes have been made to this document. Information components may have been updated such as the title page, NOTICE text, headers, and footers.

Contents

1	SCO	OPE	
	1.1 1.2	PURPOSE OF THE DOCUMENTREQUIREMENTS	
2	REI	FERENCES	2
	2.1 2.2 2.3	Normative References Informative References Reference Acquisition	2
3	ABI	BREVIATIONS	
		QUIREMENTS	
		DIX A. LOOP VOLTAGE MANAGEMENT POLICIES.	



1 SCOPE

1.1 Purpose of the Document

New objects that are being introduced beyond IPCablecom 1.0 for Signaling MIBS are being grouped in this document so that the additional changes made can be tracked easily.

1.2 Requirements

Throughout this document, the words that are used to define the significance of particular requirements are capitalized. These words are:

"MUST" This word means that the item is an absolute requirement of this specification.

"MUST NOT"

This phrase means that the item is an absolute prohibition of this specification.

"SHOULD" This word means that there may exist valid reasons in particular circumstances to

ignore this item, but the full implications should be understood and the case

carefully weighed before choosing a different course.

"SHOULD NOT"

This phrase means that there may exist valid reasons in particular circumstances

when the listed behavior is acceptable or even useful, but the full implications should be understood and the case carefully weighed before implementing any

behavior described with this label.

"MAY" This word means that this item is truly optional. One vendor may choose to

include the item because a particular marketplace requires it or because it enhances the product, for example; another vendor may omit the same item.

2 REFERENCES

The following documents contain provisions which, through reference in this text, constitute provisions of this standard. At the time of Subcommittee approval, the editions indicated were valid. All documents are subject to revision, and while parties to agreement based on this standard are encouraged to investigate the possibility of applying the most recent editions of the documents listed below, they are reminded that newer editions of those documents might not be compatible with the referenced version.

2.1 Normative References

- [1] ANSI/SCTE 165-05 2016, IPCablecom 1.5 Part 5: MTA Device Provisioning.
- [2] IETF STD 62, Simple Network Management Protocol Version 3 (SNMPv3), December 2002.
- [3] IETF RFC 2669, Cable Device Management Information Base for DOCSIS compliant Cable Modems and Cable Modem Termination Systems.
- [4] ANSI/SCTE 23-03 2010, DOCSIS 1.1 Part 3: Operations Support System Interface
- [5] IETF STD 5, Internet Protocol, September 1981.
- [6] IETF RFC 2011, SNMPv2 Management Information Base for the Internet Protocol using SMIv2, November 1996.
- [7] IETF RFC 2863, The Interfaces Group MIB, June 2000.
- [8] ANSI/SCTE 107 2009, Embedded Cable Modem Devices
- [9] CableLabs Definition MIB Specification, CL-SP-MIB-CLABDEF-I11-160317, March 17, 2016, Cable Television Laboratories, Inc.
- [10] ANSI/SCTE 79-02 2016, DOCSIS 2.0, Operations Support System Interface.
- [11] ANSI/SCTE 167-07 2016, IPCablecom 1.5 Part 7: MTA MIB.
- [12] ANSI/SCTE 165-08 2016, IPCablecom 1.5 Part 8: Signaling MIB.
- [13] ANSI/SCTE 165-06 2016, IPCablecom 1.5 Part 6: MIBs Framework Specification.
- [14] IETF RFC 2833, RTP Payload for DTMF Digits, Telephony Tones and Signals, May 2000.
- [15] ANSI/SCTE 165-02 2016, IPCablecom 1.5 Part 2: Audio/Video Codecs.
- [16] ANSI/SCTE 165-03 2016, IPCablecom 1.5 Part 3: Network-Based Call Signaling Protocol.

2.2 Informative References

In order to claim compliance with this standard, it is necessary to conform to the following standards and other works as indicated, in addition to the other requirements of this standard. Intellectual property rights may be required to implement these references.

- [17] Data-Over-Cable Service Interface Specifications, Cable Modem to Customer Premise Equipment Interface Specification, CMCI, CM-SP-CMCI-C01-081104, November 4, 2008, Cable Television Laboratories, Inc.
- [18] IETF RFC 3417, Transport Mappings for the Simple Network Management Protocol (SNMP), December 2002.
- [19] IETF RFC 2579, Textual Conventions for SMIv2, April 1999.
- [20] IETF RFC 3410, Introduction and Applicability Statements for Internet-Standard Management Framework, December 2002.

- [21] IETF RFC 3411, An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks, December 2002.
- [22] IETF RFC 3412, Message Processing and Dispatching for the Simple Network Management Protocol (SNMP), December 2002.
- [23] IETF RFC 2821, Simple Mail Transfer Protocol, April 2001.
- [24] SCTE 165-04 2016, IPCablecom 1.5 Part 4: Dynamic Quality-of-Service.
- [25] IETF RFC 3594, PacketCable Security Ticket Control Sub-Option for the DHCP CableLabs Client Configuration (CCC) Option, September 2003.
- [26] IETF RFC 2782, A DNS RR for specifying the location of services (DNS SRV), February 2000.
- [27] IETF RFC 3584, Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework, August 2003.
- [28] ANSI/SCTE 165-15 2016, IPCablecom 1.5 Part 15, Management Event MIB Specification.

2.3 Reference Acquisition

- Cable Television Laboratories, Inc., 858 Coal Creek Circle, Louisville, CO 80027; Phone +1-303-661-9100; Fax +1-303-661-9199; Internet: http://www.cablelabs.com/.
- Internet Engineering Task Force (IETF) Secretariat c/o Corporation for National Research Initiatives, 1895 Preston White Drive, Suite 100, Reston, VA 20191-5434, Phone +1-703-620-8990, Fax +1-703-620-9071, Internet: www.ietf.org/

3 ABBREVIATIONS

There are no abbreviations used in this document.

4 REQUIREMENTS

The IPCablecom Extension Signaling MIB MUST be implemented as defined below.

```
PKTC-EN-SIG-MIB DEFINITIONS ::= BEGIN
IMPORTS
     MODULE-IDENTITY,
      OBJECT-TYPE,
      Unsigned32, BITS FROM SNMPv2-SMI
      ifIndex FROM IF-MIB
      SnmpAdminString
            FROM SNMP-FRAMEWORK-MIB
      TruthValue
            FROM SNMPv2-TC
      OBJECT-GROUP,
      MODULE-COMPLIANCE
            FROM SNMPv2-CONF
      pktcEnhancements
            FROM CLAB-DEF-MIB
      pktcNcsEndPntConfigEntry
            FROM PKTC-SIG-MIB;
pktcEnSigMib MODULE-IDENTITY
      LAST-UPDATED
                      "201208130000Z" -- August 13, 2012
      ORGANIZATION
                    "Cable Television Laboratories, Inc "
      CONTACT-INFO
           "Sumanth Channabasappa
Postal: Cable Television Laboratories, Inc.
858 Coal Creek Circle
Louisville, Colorado 80027-9750
U.S.A.
Phone: +1 303-661-9100
Fax: +1 303-661-9199
E-mail: mibs@cablelabs.com"
      DESCRIPTION
            "This MIB module enhances the basic management
            objects defined for PacketCable Signaling
            protocols by the MIB group pktcSigMib.
            Acknowledgements:
            Rodney Osborne - Arris Interactive
            Eugene Nechamkin - Broadcom Corporation
            Satish Kumar - Texas Instruments
            Jean-Francois Mule - CableLabs
            Copyright 1999-2005 Cable Television Laboratories, Inc.
            All rights reserved."
      REVISION "201208130000Z" -- August 13, 2009
      DESCRIPTION
            "Revised Version includes ECNs
            MIB-EXSIG1.5-N-12.0689-2-M
            and published as part of PKT-SP-MIB-EXSIG1.5-I05-121030"
```

```
REVISION "200906150000Z" -- June 15, 2009
      DESCRIPTION
            "Revised Version includes ECNs
           MIB-EXSIG1.5-N-09.0569-2
            and published as part of PKT-SP-MIB-EXSIG1.5-I04-090624"
      REVISION "200704120000Z"
      DESCRIPTION
            "This revision is being published as part of the PacketCable
            Signaling MIBs I03 enhancements for PacketCable 1.5."
      REVISION "200508120000Z"
      DESCRIPTION
            "This revision is being published as part of the PacketCable
            Signaling MIBs enhancements for PacketCable 1.5."
      ::= { pktcEnhancements 2 }
-- Enhanced MIB Objects and Divisions.
pktcEnSigMibObjects
                               OBJECT IDENTIFIER
                                           ::= { pktcEnSigMib 1 }
pktcEnSigDevConfigObjects
                               OBJECT IDENTIFIER
                                           ::= { pktcEnSigMibObjects 1 }
pktcEnNcsEndPntConfigObjects
                               OBJECT IDENTIFIER
                                           ::= { pktcEnSigMibObjects 2 }
pktcEnSigEndPntConfigObjects
                              OBJECT IDENTIFIER
                                            ::= { pktcEnSigMibObjects 3 }
pktcEnDcsEndPntConfigObjects OBJECT IDENTIFIER
                                           ::= { pktcEnSigMibObjects 4 }
-- Enhanced Notification groups.
pktcEnSigNotificationPrefix OBJECT IDENTIFIER
                                         ::= { pktcEnSigMib 2 }
pktcEnSigNotification OBJECT IDENTIFIER
                                         ::= { pktcEnSigNotificationPrefix 0 }
pktcEnSigConformance
                       OBJECT IDENTIFIER
                                         ::= { pktcEnSigMib 3 }
pktcEnSigCompliances
                       OBJECT IDENTIFIER
                                         ::= { pktcEnSigConformance 1 }
                       OBJECT IDENTIFIER
pktcEnSigGroups
                                         ::= { pktcEnSigConformance 2 }
pktcEnNcsMinimumDtmfPlayout OBJECT-TYPE
      SYNTAX Unsigned32 (0 | 40..100)
      UNITS "milliseconds"
      MAX-ACCESS
                  read-write
       STATUS current
       DESCRIPTION
           "This object defines the minimum playout time for
           the DTMF digit when IETF RFC 2833 DTMF Relay is used
```

```
for the egress gateway.
            If the value set via this pktcEnNcsMinimumDtmfPlayout
            object is different from that specified in RFC2833 packet,
            then the MTA MUST use the maximum of the two values.
            For example:
            If the RFC 2833 packet specifies 23ms and if the object
            pktcEnNcsMinimumDtmfPlayout is set to 40ms then
            the egress gateway must use a value of 40\,\mathrm{ms}.
            Similarly if the RFC 2833 packet specifies
            60 ms and if the object pktcEnNcsMinimumDtmfPlayout
            is set to 40ms then the egress gateway must use a
            value of 60 ms."
       REFERENCE
            "PacketCable(tm) Codec Specification"
       DEFVAL {0}
       ::= { pktcEnSigDevConfigObjects 1}
      The following table enhances the NCS End Point Config Table
      (pktcNcsEndPntConfigTable) defined in pktSigMib.
pktcEnNcsEndPntConfigTable
                           OBJECT-TYPE
       SYNTAX
                    SEQUENCE OF PktcEnNcsEndPntConfigEntry
      MAX-ACCESS
                    not-accessible
       STATUS
                    current
      DESCRIPTION
            "This table augments pktcNcsEndPntConfigTable."
      ::= { pktcEnNcsEndPntConfigObjects 1 }
pktcEnNcsEndPntConfigEntry
                            OBJECT-TYPE
       SYNTAX
              PktcEnNcsEndPntConfigEntry
                  not-accessible
      MAX-ACCESS
       STATUS
                    current
       DESCRIPTION
            "An enhancement to pktcNcEndPntConfigTable - where each
            entry describes endpoint characteristics."
      AUGMENTS { pktcNcsEndPntConfigEntry }
      ::= { pktcEnNcsEndPntConfigTable 1 }
PktcEnNcsEndPntConfigEntry ::=
       SEQUENCE {
                pktcEnNcsEndPntQuarantineState INTEGER,
                pktcEnNcsEndPntHookState INTEGER,
                pktcEnNcsEndPntFaxDetection TruthValue,
                pktcEnNcsEndPntStatusReportCtrl INTEGER
        }
pktcEnNcsEndPntQuarantineState
                                OBJECT-TYPE
       SYNTAX INTEGER {
           normal
                            (1),
           notification
                            (2),
          lockstep
                            (3),
           extendedlockstep (4)
      MAX-ACCESS
                   read-only
       STATUS
       DESCRIPTION
           "This object reflects the state of the Endpoint.
```

```
When the endpoint is in notification, lockstep or
             'extended lockstep' states, the E-MTA MUST report
             the values of notification(2), lockstep(3) or extendedlockstep(
             4), respectively. Else, the endpoint MUST report a value of
           normal(1).
          'Extended Lockstep' is defined as the state when the
           E-MTA is in the lockstep state for longer than 2 minutes.
           For more description about the states refer
           to the PacketCable Network Based Call signaling
           specification."
       REFERENCE
            "PacketCable(tm) Network-Based Call Signaling Protocol
            Specification,"
      ::= { pktcEnNcsEndPntConfigEntry 1 }
pktcEnNcsEndPntHookState
                         OBJECT-TYPE
       SYNTAX INTEGER {
                  onHook
                                        (1),
                  onHookPlusNCSActivity (2),
                  offHook
                                        (3)
       MAX-ACCESS
                   read-only
       STATUS current
       DESCRIPTION
           "This object reflects the 'hook state' and 'NCS Activity'
            of an endpoint.
            'NCS Activity', by definition includes: an active
            timeout signal, active brief signal or existence of
             an NCS connection.
            The onHook(1) state indicates that the endpoint is
             'on hook' and the absence of 'NCS Activity' on that
             endpoint.
             The onHookPlusNCSActivity(2) indicates that the endpoint
             is 'on hook' and the presence of 'NCS Activity' on that
             endpoint.
             The offHook(3) state indicates that the endpoint is
             'off hook'."
       REFERENCE
            "PacketCable(tm) Network-Based Call Signaling Protocol Specification"
       ::= { pktcEnNcsEndPntConfigEntry 2 }
pktcEnNcsEndPntFaxDetection
                                 OBJECT-TYPE
      SYNTAX TruthValue
      MAX-ACCESS read-create
      STATUS
                 current
      DESCRIPTION
            "This MIB object is used to configure
            the distinctive fax calling tone (CNG) detection feature
            on an MTA endpoint with reference to the analog interface.
            When set to true, the MTA MUST enable the detection
            of CNG tones on the specific endpoint.
            When set to false, the MTA MUST disable the detection
            of CNG tones on the specific endpoint.
            If a connection already exists on the endpoint when this
            MIB Object is modified, then the setting needs to take
            effect on the next connection."
       DEFVAL {false}
      ::= { pktcEnNcsEndPntConfigEntry 3}
```

```
pktcEnNcsEndPntStatusReportCtrl
                                    OBJECT-TYPE
           SYNTAX INTEGER {
                unsupported
                                           (1),
                 reportActualStatus
                                          (2),
                 reportEndPointAsActive
                                           (3)
      MAX-ACCESS read-create
       STATUS
                  deprecated
       DESCRIPTION
           "This MIB object is be used to control
           the Endpoint Status Reporting, if the feature is
            supported by the MTA and is configurable.
           The term 'Endpoint Status Reporting' refers to any
           information that the MTA may provide to External
           Systems for use in a particular reporting mechanism
            (Ex: Home Alarm Systems). The definition of the External
           Systems and reporting mechanism are beyond the scope
            of this definition (In the example of Home Alarm Systems,
           this MIB Object will allow Management Stations to
            temporarily disable outage reporting on an EndPoint
            during planned downtime).
           If supported, the MTA MUST:
            - reflect the actual Endpoint status when the value
             is set to 'reportActualStatus(2)'
             - reflect the EndPoint status as being active when the
              value is set to 'reportEndPointAsActive(3)',
             irrespective of the actual status.
            If unsupported, the MTA MUST set this value to
            'unsupported(1)' and reject any attempt to set
            this MIB object using SNMP SET to any other value."
      ::= { pktcEnNcsEndPntConfigEntry 4}
pktcEnEndPntInfoTable OBJECT-TYPE
      SYNTAX SEQUENCE OF PktcEnEndPntInfoTableEntry
                   not-accessible
      MAX-ACCESS
       STATUS
                    current
       DESCRIPTION
           "This table includes any additional information
            associated with PacketCable EndPoints.
           The number of entries in this table represents the
           number of available PacketCable EndPoints."
      ::= { pktcEnNcsEndPntConfigObjects 2 }
pktcEnEndPntInfoTableEntry
                           OBJECT-TYPE
      SYNTAX PktcEnEndPntInfoTableEntry
     MAX-ACCESS
                   not-accessible
      STATUS
                   current.
      DESCRIPTION
           "An entry in this table MUST be created for each
           PacketCable EndPoint.
           The index needs to be the corresponding index in the ifTable
            for the associated PacketCable EndPoint."
     INDEX { ifIndex }
      ::= { pktcEnEndPntInfoTable 1 }
PktcEnEndPntInfoTableEntry ::=
       SEQUENCE {
               pktcEnEndPntFgnPotSupport
                pktcEnEndPntFgnPotDescr
                                            SnmpAdminString,
               pktcEnEndPntClrFgnPotTsts
                                            BITS,
```

```
pktcEnEndPntRunFgnPotTsts
                pktcEnEndPntFgnTestValidity BITS,
                pktcEnEndPntFgnTestResults BITS
        }
pktcEnEndPntFgnPotSupport OBJECT-TYPE
      SYNTAX BITS {
           fgnPotDetection (0),
           hazardousFgnPotDetection (1)
       MAX-ACCESS read-only
       STATUS current
       DESCRIPTION
           "This MIB object indicates the capabilities of the MTA to
            detect various conditions related to the presence of
            foreign potential on an endpoint.
            The MTA MUST set a value of '1' for each bit corresponding
            to a supported functionality and a value of '0' for each
            bit corresponding to an unsupported functionality."
       ::= { pktcEnEndPntInfoTableEntry 1 }
pktcEnEndPntFgnPotDescr OBJECT-TYPE
       SYNTAX SnmpAdminString
       MAX-ACCESS read-only
       STATUS current
       DESCRIPTION
           "This MIB object provides information related to the
            various tests for each detection mechanism supported by
            the MTA. While the actual contents are vendor-specific,
            the recommended format is:
            [<Capability>:<Test References>:<Other Info>]...
           Example:
           <fgnPotDetection>:<test XYZ, Reference 'Document'>:<NA>;
           <hazardousFngPotDetection>:<Test ABC, References>:<NA>
       ::= { pktcEnEndPntInfoTableEntry 2 }
pktcEnEndPntClrFgnPotTsts
                              OBJECT-TYPE
       SYNTAX BITS {
           clrFgnPotentialResults (0),
           clrHazardousPotResults (1)
       MAX-ACCESS
                      read-write
       STATUS
                      current
       DESCRIPTION
           "This MIB object is used to clear the current test
            results of supported conditions indicated by
            'pktcEnEndPntFgnPotSupport'.
            Setting a bit to a value of '1' clears the corresponding
            results in the MIB Object 'pktcEnEndPntFgnTestResults' and the validity as indicated by the MIB object
            'pktcEnEndPntFgnTestValidity' for the supported
            conditions only (i.e., the MTA MUST set the corresponding
            bits to a value of '0' in the indicated tables).
            If an SNMP SET attempts to set a bit corresponding to an
            unsupported condition to a value of '1', then the MTA MUST
            reject the entire SNMP SET and report an 'inconsistent
            value' error.
           For all unsupported scenarios, the corresponding bits MUST
            be set to a value of '0'.
```

```
Whenever one or more tests are enabled by the MIB Object
           'pktcEnEndPntRunFgnPotTests', the MTA MUST also reset the
            corresponding bits in this MIB Object to a value of '0'."
       ::= { pktcEnEndPntInfoTableEntry 3}
pktcEnEndPntRunFgnPotTsts
                              OBJECT-TYPE
       SYNTAX BITS {
           runFgnPotentialTsts (0),
           runHazardousPotTsts (1)
      MAX-ACCESS
                     read-write
       STATUS
                     current
       DESCRIPTION
           "This MIB object is used to initiate one or more test cases
            associated with a supported foreign potential detection.
            Thus, whenever one or more BITS corresponding to supported
            foreign scenario potential detection mechanisms are set to
            a value of '1', the MTA MUST enable those tests.
            Once the tests are executed, the MTA MUST:
            - set the corresponding bit to a value of '0'
            - update the corresponding BITS in the MIB Objects
            'pktcEnEndPntFgnTestValidity' and
            'pktcEnEndPntFqnTestResults'.
            If an SNMP SET attempts to set a bit corresponding to an
            unsupported condition to a value of '1', then the MTA MUST
            reject the entire SNMP SET and report an 'inconsistent
            value' error.
            Whenever a test is being run on an EndPoint the MTA MUST
            set the corresponding 'ifOperStatus' MIB Object to a
            value of 'testing(3)' for the whole duration of the test.
            When the test is completed, the MTA MUST set the
            ifOperStatus to the value corresponding to the current
            state of the line.
           Note: Whenever multiple tests are run, the ordering of the
                 tests or the results is vendor dependent and need not
                 necessarily follow the ordering of BITS in this MIB
                 Object."
       ::= { pktcEnEndPntInfoTableEntry 4}
pktcEnEndPntFgnTestValidity OBJECT-TYPE
       SYNTAX BITS {
           fgnPotTstValidity (0),
           hazardousPotTstValidity (1)
      MAX-ACCESS
                     read-only
       STATUS
                     current
       DESCRIPTION
           "This MIB object is used to indicate the validity of the
            corresponding test cases that were initiated using the MIB
            Object 'pktcEnEndPntRunFqnPotTests'.
            An MTA MUST:
            - return a value of '1' if the tests were run successfully
              and the results are valid.
            - return a value of '0' if a particular test was not
             initiated or if the tests could not be run successfully
             and hence the results are invalid.
           Note: The MTA MUST set all the BITS to '0' as soon as one
                  or more test cases are initiated."
      ::= { pktcEnEndPntInfoTableEntry 5}
```

```
pktcEnEndPntFqnTestResults OBJECT-TYPE
       SYNTAX BITS {
           fgnPotentialResults (0),
           hazardousPotResults (1)
      MAX-ACCESS
                     read-only
      STATUS
                     current
       DESCRIPTION
           "This MIB object is used to indicate the results of the
            corresponding test cases that were initiated using the MIB
            Object 'pktcEnEndPntRunFgnPotTests'.
           An MTA MUST:
            - set the corresponding bit to a value of '1' if the tests
             indicated the presence of a foreign potential as per the
             associated test case.
            - set the corresponding bit to a value of '0' if the tests
              indicated the absence of a foreign potential as per the
              associated test case.
           Note: The MTA MUST set all the BITS to '0' as soon as one or
                 more test cases are initiated."
       ::= { pktcEnEndPntInfoTableEntry 6}
pktcEnNcsEndPntLVMgmtTable
                            OBJECT-TYPE
       SYNTAX
                    SEQUENCE OF PktcEnNcsEndPntLVMgmtTableEntry
      MAX-ACCESS
                    not-accessible
      STATUS
                    current
      DESCRIPTION
       "This MIB table contains the MIB Objects used for
      managing loop voltage on an MTA. An MTA MUST
      implement the defined MIB Objects and the associated
      functionality."
      ::= { pktcEnNcsEndPntConfigObjects 3 }
pktcEnNcsEndPntLVMgmtTableEntry
                                OBJECT-TYPE
                  PktcEnNcsEndPntLVMgmtTableEntry
      SYNTAX
      MAX-ACCESS
                   not-accessible
      STATUS
                   current
      DESCRIPTION
      "Each entry in this MIB table consists of the
      loop voltage management policy for the specified
      index. The MTA MUST use the ifIndex with a value of '1'
      to represent the E-MTA and the remaining indices
       (if used) to represent the endpoints (as specified
      in [1]).
      When the ifIndex is set to a value of '1', it represents
      a policy that MUST be applied to all the lines on an MTA.
      A MTA MUST support access to this MIB Object via the
      ifIndex set to a value of '1' (i.e., per-device policy). "
      REFERENCE "PacketCable Device Provisioning specification [1]"
      INDEX { ifIndex }
      ::= { pktcEnNcsEndPntLVMgmtTable 1 }
PktcEnNcsEndPntLVMgmtTableEntry ::=
       SEQUENCE {
               pktcEnNcsEndPntLVMgmtPolicy
                                                  INTEGER,
                                                  Unsigned32,
               pktcEnNcsEndPntLVMgmtResetTimer
               pktcEnNcsEndPntLVMgmtMaintTimer
                                                  Unsigned32
pktcEnNcsEndPntLVMgmtPolicy OBJECT-TYPE
```

```
SYNTAX INTEGER {
   voltageAtAllTimes(1),
   voltageUnlessRFQAMAbsent(2),
   voltageBasedOnServiceOrTimers(3),
   voltageBasedOnService(4)
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"This MIB Object allows the Service Provider to choose
a suitable policy for Loop Voltage behavior on MTAs.
Unless overridden by the operator, the MTA MUST use the
default value specified in the definition of this MIB
Object.
The MTA MUST adhere to PacketCable signaling
requirements, such as the NCS open loop voltage requirement,
irrespective of any chosen policy.
For MTAs that need to remove loop voltage during the MTA
initialization phase, in contradiction to a chosen policy,
such a loop voltage removal period MUST NOT exceed 1000ms.
The MTA MUST retain the value of this MIB Object across
hard reboots or soft resets (for a definition of the terms,
please refer to [1]).
This MIB object specifies four policies. An informative
illustration of the E-MTA behavior with different policies
is presented in Appendix A.
Provisioned line is an MTA Endpoint that has been provided
with valid per-line configuration data either via the
configuration file (during provisioning) or the SNMP
management interface.
When the MIB Object is set to a value of
'voltageAtAllTimes', - indicating Policy 1 -
the MTA MUST maintain the loop idle voltage on all
lines, irrespective of the line status.
When this MIB Object is set to a value of
'voltageUnlessRFQAMAbsent' - indicating Policy 2
- the MTA MUST apply loop idle voltage at all
times except when it confirms the absence of any
RF QAM carrier, following a complete scan of the
spectrum (i.e., loop voltage is maintained during
the scan). When the MTA detects the presence of any
RF QAM carrier, it MUST apply the loop idle voltage.
Additionally, the following conditions apply:
  - during a hard reboot, this policy applies at all
    lines until the MTA is successfully provisioned (
    i.e., pktcMtaDevProvisioningState has a value
   other than 'inProgress')
  - once the MTA is successfully provisioned (
    (i.e., pktcMtaDevProvisioningState has a value
    of 'pass(1)', 'passWithWarnings(4)' or
    'passWithIncompleteParsing(5)') then the policy
```

applies to all provisioned lines
- upon the onset of a re-initialization due to a
soft reset (via SNMP or Rf conditions) the MTA MUST
continue to maintain the existing policy and state
on previously provisioned lines, unless overridden
by a policy or the provisioning process specifies
otherwise

This policy is similar to Policy 1, except for the ability to recognize events like cable cuts (due to malicious activities, or otherwise).

The following requirements apply to policies 3 and 4:

- upon the onset of a re-initialization due to a soft reset the MTA MUST continue to maintain the existing policy and state on provisioned lines, unless overridden by a policy or the provisioning process specifies otherwise
- once the provisioning process is completed with the value of the MIB Object pktcMtaDevProvisioningState set to a value of 'pass(1)', 'passWithWarnings(4)' or 'passWithIncompleteParsing(5)', the MTA MUST apply the chosen policy to all the provisioned lines

When this MIB Object is set to a value of 'voltageBasedOnServiceOrTimers' - indicating Policy 3 - the MTA MUST adhere to the requirements that follow at any given point in time:

- when the timer defined by pktcEnNcsEndPntLVMgmtResetTimer has a non-zero value, the MTA MUST apply loop idle voltage under all circumstances (similar to policy 1). Refer to the definition of the MIB Object for the persistence and timer requirements.
- when the timer defined by pktcEnNcsEndPntLVMgmtMaintTimer has a non-zero value, the MTA MUST maintain a line's loop idle voltage state that was in effect prior to the timer being set to a non-zero value. Refer to the definition of the MIB Object defining the timer for the persistence and timer requirements.
- When the timers defined by pktcEnNcsEndPntLVMgmtMaintTimer and pktcEnNcsEndPntLVMgmtResetTimer have expired (both have a value of zero), then:
 - = the MTA MUST apply loop voltage if the provisioning process is completed with the value of pktcMtaDevProvisioningState set to a value of than 'pass(1)', 'passWithWarnings(4)' or 'passWithIncompleteParsing(5)'
 - = During a T4 timeout (note: the timers have expired), the E-MTA MUST remove loop idle voltage on all lines
- When both the timers are active (i.e., they both have non-zero values), then the timer defined by the MIB Object pktcEnNcsEndPntLVMgmtMaintTimer takes precedence
- if none of the above cases apply, the MTA MUST remove loop idle voltage on all lines

```
When the MIB Object is set to a value of
     'voltageBasedOnService' - indicating Policy 4 - the
     following conditions apply at any given point in time:
         - the MTA MUST apply loop idle voltage to all
         the provisioned lines if the value of the MIB Object
         'pktcMtaDevProvisioningState' is set to a
         value of 'pass(1)', 'passWithWarnings(4)'
         or 'passWithIncompleteParsing(5)'
         - in all other cases, the MTA
        MUST remove loop idle voltage on all lines."
    REFERENCE "PacketCable Device Provisioning specification [1]"
     DEFVAL { voltageBasedOnService }
      ::= { pktcEnNcsEndPntLVMgmtTableEntry 1}
pktcEnNcsEndPntLVMgmtResetTimer OBJECT-TYPE
    SYNTAX Unsigned32 (0..1440)
    UNITS "minutes"
    MAX-ACCESS read-write
     STATUS current
     DESCRIPTION
     "This MIB Object specifies the time duration allowed for
     an MTA to successfully provision and is only applicable when
    the MIB Object pktcEnNcsEndPntLVMgmtPolicy is
    set to a value of 'voltageBasedOnServiceOrTimers'.
    In all other cases, the MTA MUST:
        - return a value of '0' upon any retrieval requests
        - return an error of 'inconsistentValue' upon any
         modification requests
    The value contained by this MIB Object is a countdown timer
     and the MTA MUST start counting down the configured value
     only upon a hard reboot, a soft reset or a T4 timeout. Once
     this timer has reached a value of zero, the MTA MUST retain
     the value (of zero) until successfully configured otherwise.
    The MTA MUST use a change in the value of this MIB Object
     only on the next hard reboot, soft reset or T4 timeout.
    The MTA MUST persist the last configured value (i.e., not
    the countdown value) of this MIB Object across hard reboots
    and soft resets.
    Refer to the MIB Object pktcEnNcsEndPntLVMgmtPolicy for
    usage within 'voltageBasedOnServiceOrTimers'."
    DEFVAL { 5 }
      ::= { pktcEnNcsEndPntLVMgmtTableEntry 2}
pktcEnNcsEndPntLVMgmtMaintTimer OBJECT-TYPE
SYNTAX Unsigned32 (0..1440)
    UNITS "minutes"
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
    "This MIB Object allows the operator to specify the time that
     loop voltage condition will be maintained, irrespective of
     the changes to the MTA. It is only applicable when the MIB
    Object pktcEnNcsEndPntLVMgmtPolicy is set to a
    value of 'voltageBasedOnServiceOrTimers'. In all
```

```
other cases, the MTA MUST:
       - return a value of '0' upon any retrieval requests
       - return an error of 'inconsistentValue' upon any
         modification requests
    The value contained in this MIB Object is a countdown timer
    and the MTA MUST start counting down the value immediately
     after a successful configuration to a non-zero value. Once
     this timer has reached a value of zero, the MTA MUST retain
     the value (of zero) until successfully configured otherwise.
    The MTA MUST retain the value of this MIB Object (i.e., the
    countdown value) across soft resets. The MTA MUST reset the
    value of this MIB Object (to its default value) during a
    hard reboot of the MTA.
    Refer to the MIB Object pktcEnNcsEndPntLVMgmtPolicy for
    information about applicability and usage."
    DEFVAL { 0 }
     ::= { pktcEnNcsEndPntLVMgmtTableEntry 3}
-- The Provisioned Loss Plan Table
pktcEnNcsEndPntLossTable OBJECT-TYPE
    SYNTAX SEQUENCE OF PktcEnncsEndPntLossEntry
   MAX-ACCESS not-accessible
   STATUS
               current.
    DESCRIPTION
        " The E-MTA supports two provisioned loss parameters, one for
          the D/A direction (towards the subscriber) and one for A/D
          direction (from the subscriber) direction. This data table
         represents the loss for each line provided by the E-MTA."
    ::= { pktcEnNcsEndPntConfigObjects 4 }
pktcEnNcsEndPntLossEntry OBJECT-TYPE
               PktcEnNcsEndPntLossEntry
    SYNTAX
   MAX-ACCESS not-accessible
    STATUS
               current
    DESCRIPTION
        " The E-MTA supports two provisioned loss parameters, one for
         the D/A direction (towards the subscriber) and one for A/D
          direction (from the subscriber) direction. This data table
          represents the loss for each line provided by the E-MTA.
         Each entry in this data table describes the loss
          for the associated line."
    INDEX { ifIndex }
    ::= { pktcEnNcsEndPntLossTable 1 }
PktcEnNcsEndPntLossEntry ::=
    SEQUENCE {
              pktcEnNcsEndPntLossDA
                                              Integer32,
             pktcEnNcsEndPntLossAD
                                              Integer32
pktcEnNcsEndPntLossDA OBJECT-TYPE
    SYNTAX
               Integer32 (0..12)
               "dB"
   UNITS
   MAX-ACCESS read-write
               current
    STATUS
    DESCRIPTION
```

```
" This object specifies the provisioned loss parameter
          for the D/A direction (towards the subscriber) in dB.
          The E-MTA MUST implement this element per the PacketCable Embedded
          MTA Analog Interface and Powering Specification."
    REFERENCE "PacketCable AIP Specification"
    DEFVAL {9}
    ::= { pktcEnNcsEndPntLossEntry 1 }
pktcEnNcsEndPntLossAD OBJECT-TYPE
    SYNTAX
            Integer32 (0..6)
               "dB"
    UNITS
   MAX-ACCESS read-write
    STATUS
               current
    DESCRIPTION
        " This object specifies the provisioned loss parameter
          for the A/D direction (from the subscriber) in dB.
          The E-fMTA MUST implement this element per the PacketCable Embedded
          MTA Analog Interface and Powering Specification."
    REFERENCE "PacketCable AIP Specification"
    DEFVAL {3}
    ::= { pktcEnNcsEndPntLossEntry 2 }
-- Compliance statements
pktcEnSigBasicCompliance MODULE-COMPLIANCE
       STATUS
                 current
       DESCRIPTION
           "The compliance statement for devices that implement
           PacketCable defined Signaling on an MTA."
      MODULE PKTC-EN-SIG-MIB
-- Mandatory groups
MANDATORY-GROUPS {
        pktcEnSigGroup
       GROUP pktcEnNcsGroup
       DESCRIPTION
           "This group is mandatory for any MTA implementing
            PacketCable signaling."
       GROUP pktcEnNcsLVMgmtGroup
       DESCRIPTION
           "This group is mandatory for any MTA implementing
            PacketCable signaling."
       ::={ pktcEnSigCompliances 1 }
-- Conformance group for common Signaling.
pktcEnSigGroup OBJECT-GROUP
       OBJECTS {
```

```
pktcEnNcsMinimumDtmfPlayout
       STATUS current
       DESCRIPTION
           "Enhanced group of objects for the common portion of the
           PacketCable Signaling MIB."
      ::= { pktcEnSigGroups 1 }
-- Conformance group for NCS Signaling.
pktcEnNcsGroup OBJECT-GROUP
       OBJECTS {
       pktcEnNcsEndPntQuarantineState,
        pktcEnNcsEndPntHookState,
       pktcEnNcsEndPntFaxDetection,
       pktcEnEndPntFgnPotSupport,
        pktcEnEndPntFgnPotDescr,
        pktcEnEndPntClrFgnPotTsts,
        pktcEnEndPntRunFgnPotTsts,
        pktcEnEndPntFgnTestValidity,
        pktcEnEndPntFgnTestResults,
        pktcEnNcsEndPntLossDA,
       pktcEnNcsEndPntLossAD
       STATUS current
       DESCRIPTION
           "Enhanced group of objects for the NCS portion of the
            PacketCable Signaling MIB. This is mandatory for
            NCS signaling support."
       ::= { pktcEnSigGroups 2 }
-- Conformance group for Loop Voltage Management
pktcEnNcsLVMgmtGroup OBJECT-GROUP
       OBJECTS {
           pktcEnNcsEndPntLVMgmtPolicy,
           pktcEnNcsEndPntLVMgmtResetTimer,
           pktcEnNcsEndPntLVMgmtMaintTimer
       STATUS current
       DESCRIPTION
           "Enhanced group of objects for the loop voltage
           Management of PacketCable MTAs based on Signaling
            and configured policies."
      ::= { pktcEnSigGroups 3 }
pktcEnNcsDeprecatedGroup OBJECT-GROUP
       OBJECTS {
           pktcEnNcsEndPntStatusReportCtrl
       STATUS deprecated
       DESCRIPTION
          "This contains a list of deprecated Extension
           Signaling MIB Objects."
      ::= { pktcEnSigGroups 4 }
END
```

Appendix A. Loop Voltage Management Policies

This appendix provides an illustration of the loop voltage management policies defined by the MIB Object pktcEnNcsEndPntLVMgmtPolicy. Please note that this is an informative illustration and the MIB Object definition is normative under all circumstances.

Stage	Policy 1	Policy 2	Policy 3	Policy4 (default)
Boot loader initialization following a hard reboot	unspecified	unspecified	unspecified	unspecified
Boot loader initialization following a soft reset	Same status as prior to reset	Same status as prior to reset	Same status as prior to reset	Same status as prior to reset
DOCSIS RF Scan	APPLY voltage on all lines	APPLY for first full pass through spectrum, REMOVE if no QAM lock occurred; REAPPLY if QAM returns	APPLY until Maintenance Timer and Voltage Reset Timeout expire; REMOVE thereafter	REMOVE voltage
eCM Ranging/Registering	APPLY	APPLY	Same status as final state from scanning; REMOVE if timers expire;	REMOVE
eCM provisioning process	APPLY	Same status as final state from scanning	Same status as final state from scanning; REMOVE if timers expire	REMOVE
Loss of Rf signal prior to T4	APPLY	APPLY	APPLY	APPLY
DOCSIS Rf scanning after T4	APPLY	APPLY for first full pass through spectrum, REMOVE if no QAM lock occurred; REAPPLY if QAM returns	APPLY until timers expire, REMOVE thereafter	REMOVE
eMTA provisioning (MTA1 onwards, while pktcMtaDevProvisioningState is set to a value of 'inProgress')	APPLY	Same status as final state from Rf scanning	APPLY until timers expire, REMOVE thereafter	REMOVE
E-MTA is operational and the eMTA MIB Object pktcMtaDevProvisioningState is set to a value of 'pass', 'passWithWarnings' or 'passWithIncompleteParsing'	APPLY	APPLY	APPLY	APPLY
E-MTA is operational, the eMTA provisioning is completed, but the MTA's MIB Object pktcMtaDevProvisioningState is set to a value *other than * 'pass', 'passWithWarnings' or 'passWithIncompleteParsing'	APPLY	APPLY	APPLY until timers expire, REMOVE thereafter	REMOVE