SCTE STANDARDS

Network Operations Subcommittee

AMERICAN NATIONAL STANDARD

ANSI/SCTE 84-1 2017 (R2022)

HMS Common Inside Plant
Management Information Base (MIB)
Part 1: SCTE-HMS-HE-COMMON-MIB

NOTICE

The Society of Cable Telecommunications Engineers (SCTE) Standards and Operational Practices (hereafter called "documents") are intended to serve the public interest by providing specifications, test methods and procedures that promote uniformity of product, interoperability, interchangeability, best practices, and the long term reliability of broadband communications facilities. These documents shall not in any way preclude any member or non-member of SCTE from manufacturing or selling products not conforming to such documents, nor shall the existence of such standards preclude their voluntary use by those other than SCTE members.

SCTE assumes no obligations or liability whatsoever to any party who may adopt the documents. Such adopting party assumes all risks associated with adoption of these documents and accepts full responsibility for any damage and/or claims arising from the adoption of such documents.

NOTE: The user's attention is called to the possibility that compliance with this document may require the use of an invention covered by patent rights. By publication of this document, no position is taken with respect to the validity of any such claim(s) or of any patent rights in connection therewith. If a patent holder has filed a statement of willingness to grant a license under these rights on reasonable and nondiscriminatory terms and conditions to applicants desiring to obtain such a license, then details may be obtained from the standards developer. SCTE shall not be responsible for identifying patents for which a license may be required or for conducting inquiries into the legal validity or scope of those patents that are brought to its attention.

Patent holders who believe that they hold patents which are essential to the implementation of this document have been requested to provide information about those patents and any related licensing terms and conditions. Any such declarations made before or after publication of this document are available on the SCTE web site at https://scte.org.

All Rights Reserved
© 2022 Society of Cable Telecommunications Engineers, Inc.
140 Philips Road
Exton, PA 19341

DOCUMENT TYPES AND TAGS Document Type: Specification Document Tags: ☐ Test or Measurement ☐ Checklist ☐ Facility ☐ Architecture or Framework ☐ Metric ☐ Access Network ☐ Procedure, Process or ☐ Cloud ☐ Customer Premises Method

DOCUMENT RELEASE HISTORY

Release	Date
SCTE 84-1 2003	05/09/2003
SCTE 84-1 2009	07/10/2009
SCTE 84-1 2017	08/28/2017

Note: Standards that are released multiple times in the same year use: a, b, c, etc. to indicate normative balloted updates and/or r1, r2, r3, etc. to indicate editorial changes to a released document after the year.

Note: This document is a reaffirmation of SCTE 84-1 2017. No substantive changes have been made to this document. Information components may have been updated such as the title page, NOTICE text, headers, and footers.

CONTENTS

5
5
5
5
5
6

SCOPE

This document is identical to SCTE 84-1 2009 except for informative components which may have been updated such as the title page, NOTICE text, headers and footers. No normative changes have been made to this document.

The MIB module is for representing general information about optical equipment present in the headend (or indoor) and is supported by an SNMP agent.

COPYRIGHT

The MIB definition found in this document may be incorporated directly in products without further permission from the copyright owner, SCTE.

NORMATIVE REFERENCE

IETF RFC2578, Structure of Management Information Version 2 (SMIv2)

IETF RFC2579, Textual Conventions for SMIv2

IETF RFC2580, Conformance Statements for SMIv2

IETF RFC2737, Entity MIB (Version 2)

ANSI/SCTE 36, SCTE Root Management Information Block (MIB)

SCTE 38-11, Hybrid Management Sub-layer Management Information Base (MIB) Part 11: SCTE-HMS-HEADENDIDENT-MIB

IETF RFC2573, SNMP Applications

IETF RFC1907, Management Information Base for Version 2 of the Simple Network Management Protocol (SNMPv2)

ANSI/SCTE 38-1, Hybrid Management Sublayer Management Information Blocks (MIB) Part 1: Property MIB

INFORMATIVE REFERENCE

None

TERMS AND DEFINITIONS

This document defines the following terms:

Management Information Base (MIB) - the specification of information in a manner that allows standard access through a network management protocol.

REQUIREMENTS

This section defines the mandatory syntax of the SCTE-HMS-HE-COMMON-MIB. It follows the IETF Simple Network Management Protocol (SNMP) for defining managed objects.

The syntax is given below:

```
-- Module Name: HMS111R9.MIB (SCTE 84-1)
-- SCTE Status: Adopted
SCTE-HMS-HE-COMMON-MIB DEFINITIONS ::= BEGIN
IMPORTS
 Integer32, MODULE-IDENTITY, OBJECT-TYPE, NOTIFICATION-TYPE
    FROM SNMPv2-SMI
 DisplayString, DateAndTime
   FROM SNMPv2-TC
 MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP
   FROM SNMPv2-CONF
  entPhysicalIndex
   FROM ENTITY-MIB
 scteHmsTree
   FROM SCTE-ROOT -- see SCTE 36 (formerly HMS028)
 heCommon, HeTenthCentigrade
   FROM SCTE-HMS-HEADENDIDENT-MIB; -- see SCTE 38-11 (formerly HMS114)
heCommonMib MODULE-IDENTITY
 LAST-UPDATED "200302170000Z" -- February 17, 2003
 ORGANIZATION "SCTE HMS Working Group"
  CONTACT-INFO
      " SCTE HMS Subcommittee, Chairman
      mailto:standards@scte.org
 DESCRIPTION
     "The MIB module is for representing general information
     about optical equipment present in the headend (or indoor)
     and is supported by an SNMP agent."
 REVISION "200302170000Z" -- February 17, 2003
 DESCRIPTION
   Incorporated RTF comments posted by January 10, 2003.
```

```
::= { heCommon 1 }
heCommonObjects OBJECT IDENTIFIER ::= { heCommonMib 1 }
-- MIB contains 2 groups
heCommonParams OBJECT IDENTIFIER ::= { heCommonObjects 1 }
heCommonLog OBJECT IDENTIFIER ::= { heCommonObjects 2 }
-- The Common Table
heCommonTable OBJECT-TYPE
 SYNTAX SEQUENCE OF HeCommonEntry
  MAX-ACCESS not-accessible
  STATUS current
 DESCRIPTION
      "A table containing information about headend (or indoor)
     equipment."
  ::= { heCommonParams 1 }
heCommonEntry OBJECT-TYPE
 SYNTAX HeCommonEntry
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
      "Information about particular headend equipment."
           { entPhysicalIndex }
  INDEX
  ::= { heCommonTable 1 }
HeCommonEntry ::= SEQUENCE {
 heCommonTime
                           DateAndTime,
 heCommonTemperature
                              HeTenthCentigrade,
 heCommonSoftwareReset
                              INTEGER,
  heCommonAlarmDetectionControl
                                 INTEGER
heCommonTime OBJECT-TYPE
  SYNTAX DateAndTime
  MAX-ACCESS read-write
```

```
STATUS current
  DESCRIPTION
      "Real time clock."
  ::= { heCommonEntry 1 }
heCommonTemperature OBJECT-TYPE
 SYNTAX HeTenthCentigrade
 MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
      "Temperature measured inside the headend equipment.
      This object must provide for the alarm management capabilities
      with a corresponding entry in the propertyTable of
      SCTE-HMS-PROPERTY-MIB (HMS026).
      An alarm shall be recorded as an entry in the currentAlarmTable
      of SCTE-HMS-PROPERTY-MIB (HMS026).
      A log record shall be added as an entry in the heCommonLogTable.
      An heCommonAlarmEvent notification shall be sent."
  ::= { heCommonEntry 2 }
heCommonSoftwareReset OBJECT-TYPE
 SYNTAX INTEGER { reset(1) }
  MAX-ACCESS read-write
  STATUS current
  DESCRIPTION
      "This object is used to reset software of the headend physical
      entity.
      A SET request with the value reset(1) only shall reset
      the software application. The reset implementation is
      vendor specific.
```

A GET request shall always return the value reset(1) and

```
shall have no effect on the entity."

::= { heCommonEntry 3 }

heCommonAlarmDetectionControl OBJECT-TYPE

SYNTAX INTEGER {
    detectionDisabled(1),
    detectionEnabled(2),
    detectionEnabledAndRegenerate(3)
}

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object is used to control the detection of alarms in this headend entity.
```

Each headend entity may provide for the alarm management capabilities. The provisions shall be done by means of the propertyTable and/or the discretePropertyTable of SCTE-HMS-PROPERTY-MIB (HMS026).

When a threshold from either the propertyTable or the discretePropertyTable is crossed in a manner described by SCTE-HMS-PROPERTY-MIB (HMS026), then an alarm is said to have occurred. When the alarm is detected, then

- (1) an entry is placed in the heCommonLogTable, which serves as a log of the most recent alarm events;
- (2) an heCommonAlarmEvent trap is generated;
- (3) a property which is not in the nominal state will have an entry in the currentAlarmTable of SCTE-HMS-PROPERTY-MIB.

The detectionDisabled(1) value prevents the threshold detection process associated with the property table and discrete property table from running. The headend entity shall not generate alarms. The contents of the heCommonLogTable, currentAlarmTable, each

instance of discreteAlarmState, and each instance of currentAlarmState shall remain in the state prior to detectionDisabled(1) being applied.

The detectionEnabled(2) value permits alarm detection to run. The detection process continues from the state the headend entity was in prior to detectionEnabled(2) being set.

The detectionEnabledAndRegenerate(3) value clears all alarm information and permits alarm detection to run. All alarm properties, both discrete and analog, are restored to the nominal value before alarm detection runs. Any properties that are in an alarm state SHALL NOT produce a 'return to normal' alarm as part of the process. Setting this value clears the heCommonLogTable and the currentAlarmTable.

The detectionEnabledAndRegenerate(3) value is transient, that is a SET request with a value detectionEnabledAndRegnerate(3) shall return the same value detectionEnabledAndRegnerate(3). Subsequent GET requests shall return a value detectionEnabled(2).

The detectionDisabled(1) value shall affect the generation of heCommonAlarmEvent trap only. Traps added in the future are assumed to be unaffected by this object, unless stated in the description of that trap.

This object has a default value of detectionEnabled(2).

The value shall be maintained in non-volatile memory." ::= { heCommonEntry 4 }

-- The Common Log Group and Table heCommonLogNumberOfEntries OBJECT-TYPE SYNTAX Integer32 (0..65535) MAX-ACCESS read-only STATUS current DESCRIPTION

```
"The current number of entries in the heCommonLogTable.
      Before the very first wrap-around condition occurs
      for heCommonLogIndex, heCommonLogNumberOfEntries will
      return the total number of entries logged in heCommonLogTable,
      since the unit was powered up.
      After the first wrap-around condition has occured for
      for the value of the MIB variable heCommonLogIndex,
      heCommonLogNumberOfEntries will return the maximum
      number of rows the heCommonLogTable can hold.
  ::= { heCommonLog 1 }
heCommonLogLastIndex OBJECT-TYPE
  SYNTAX Integer32 (0..65535)
 MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
      "Index of the most recent alarm entry logged in the
      heCommonLogTable. The value of this variable can be
      used as the value of heCommonLogIndex to retrieve the
      most recent logged entry."
  ::= { heCommonLog 2 }
heCommonLogTable OBJECT-TYPE
 SYNTAX SEQUENCE OF HeCommonLogEntry
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
      "A list of alarms that have been logged.
      Agent should generate the SNMP HMS notification every time a
      new alarm entry is logged.
      This table should support a minimum of 16 entries."
  ::= { heCommonLog 3 }
heCommonLogEntry OBJECT-TYPE
  SYNTAX HeCommonLogEntry
  MAX-ACCESS not-accessible
```

```
STATUS current
  DESCRIPTION
      "A set of data describing an alarm event that has
      been logged."
            { heCommonLogIndex }
  INDEX
  ::= { heCommonLogTable 1 }
HeCommonLogEntry ::= SEQUENCE {
  heCommonLogIndex Integer32,
  heCommonLogOID OBJECT IDENTIFIER,
  heCommonLogValue Integer32,
  heCommonLogState INTEGER,
  heCommonLogTime DateAndTime,
  heCommonLogText DisplayString
heCommonLogIndex OBJECT-TYPE
  SYNTAX Integer32 (1..65535)
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
      "An index that uniquely identifies an entry
      in the log table. Indexes are assigned beginning with 1
      and increased by one with each new log entry up to 65535.
      The next entry after 65535 is one. The agent may choose to
      delete the oldest instances of heCommonLogEntry as required
      because of lack of memory. It is an implementation-specific
      matter as to when this deletion may occur.
      Note - The wrap-around for the heCommonLogIndex variable
      MUST occur after 65535 regardless of the implementation
      specific size of the hlCommonLogTable."
  ::= { heCommonLogEntry 1 }
heCommonLogOID OBJECT-TYPE
  SYNTAX OBJECT IDENTIFIER
  MAX-ACCESS read-only
  STATUS current
```

```
DESCRIPTION
      "This is the OID of the object that has changed alarm state."
  ::= { heCommonLogEntry 2 }
heCommonLogValue OBJECT-TYPE
  SYNTAX Integer32 (-2147483648..2147483647)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
      "This is the value of the object at the time it changed alarm
      state."
  ::= { heCommonLogEntry 3 }
heCommonLogState OBJECT-TYPE
  SYNTAX INTEGER {
   heCommonNominal(1),
   heCommonHIHI(2),
   heCommonHI(3),
   heCommonLO(4),
   heCommonLOLO(5),
   heCommonDiscreteMajor(6),
   heCommonDiscreteMinor(7)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
      "The new alarm state of the object which caused the event
      to be recorded into the log."
  ::= { heCommonLogEntry 4 }
heCommonLogTime OBJECT-TYPE
  SYNTAX DateAndTime
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
      "This is the time when the alarm change for the object
      occured."
```

```
::= { heCommonLogEntry 5 }
heCommonLogText OBJECT-TYPE
  SYNTAX DisplayString
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
      "This is a text field describing the alarm. This
      field could be a zero length string in certain
      agent implementations."
  ::= { heCommonLogEntry 6 }
-- Headend Common MIB Trap Definitions
heCommonTraps OBJECT IDENTIFIER ::= { heCommonMib 2 }
heCommonTrapPrefix OBJECT IDENTIFIER ::= { scteHmsTree 0 }
heCommonAlarmEvent NOTIFICATION-TYPE
  OBJECTS {
   heCommonLogOID,
   heCommonLogValue,
   heCommonLogState,
   heCommonLogTime
  STATUS current
  DESCRIPTION
      "The SNMP trap that is generated when an alarm event is found.
      At the option of the unit, the heCommonLogText variable may be
      reported as a fifth varbind, for those instances where an
      additional text field is supported."
  ::= { heCommonTrapPrefix 5 }
-- Conformance information
heCommonConformance OBJECT IDENTIFIER ::= { heCommonMib 3 }
heCommonCompliances OBJECT IDENTIFIER ::= { heCommonConformance 1 }
heCommonGroups OBJECT IDENTIFIER ::= { heCommonConformance 2 }
```

```
-- Compliance statements
heCommonCompliance MODULE-COMPLIANCE
  STATUS current
  DESCRIPTION
      "The compliance statement for SNMP entities which implement
      this MIB."
  MODULE -- this module
   MANDATORY-GROUPS { heCommonLogGroup,
             heCommonNotificationsGroup
  MODULE ENTITY-MIB
   MANDATORY-GROUPS { entityPhysicalGroup,
             entityPhysical2Group,
             entityGeneralGroup,
             entityNotificationsGroup
  MODULE SNMP-TARGET-MIB
   MANDATORY-GROUPS { snmpTargetBasicGroup }
  MODULE SNMP-NOTIFICATION-MIB
   MANDATORY-GROUPS { snmpNotifyGroup }
  MODULE SNMPv2-MIB
   MANDATORY-GROUPS { systemGroup }
-- The OBJECT clauses below indicate the optional objects of
-- the systemGroup. They also imply that other objects of
-- the group must be implemented:
-- sysDescr,
-- sysObjectID,
-- sysUpTime,
-- sysContact,
-- sysName,
-- sysLocation,
-- sysServices.
```

```
sysORDescr
     OBJECT
     MIN-ACCESS not-accessible
     DESCRIPTION
          "Implementation of this object is optional."
     OBJECT sysORID
     MIN-ACCESS not-accessible
     DESCRIPTION
          "Implementation of this object is optional."
                sysORLastChange
     OBJECT
     MIN-ACCESS not-accessible
     DESCRIPTION
          "Implementation of this object is optional."
     OBJECT sysORUpTime
     MIN-ACCESS not-accessible
     DESCRIPTION
          "Implementation of this object is optional."
 MODULE SCTE-HMS-PROPERTY-MIB
   MANDATORY-GROUPS { analogAlarmsGroup,
               discreteAlarmsGroup,
               currentAlarmsGroup
 ::= { heCommonCompliances 1 }
-- MIB groupings
heCommonParamsGroup OBJECT-GROUP
 OBJECTS {
      heCommonTime,
       heCommonTemperature,
       heCommonSoftwareReset.
       heCommonAlarmDetectionControl
```

```
STATUS current
  DESCRIPTION
      "The collection of objects which are used to represent the
      common parameters of the headend managed entities."
  ::= { heCommonGroups 1 }
heCommonLogGroup OBJECT-GROUP
  OBJECTS {
       heCommonLogNumberOfEntries,
       heCommonLogLastIndex,
       heCommonLogOID,
       heCommonLogValue,
       heCommonLogState,
       heCommonLogTime,
       heCommonLogText
  STATUS current
  DESCRIPTION
      "The collection of objects which are used to record
      an alarm event into the headend agent log."
  ::= { heCommonGroups 2 }
heCommonNotificationsGroup NOTIFICATION-GROUP
  NOTIFICATIONS { heCommonAlarmEvent }
  STATUS current
  DESCRIPTION
      "The collection of notifications used by the headend agent
      to report the exceptional conditions to the management
      application."
  ::= { heCommonGroups 3 }
END
```